


# INVT Flex Series I/O System EtherCAT Branch Module

## User Manual



# Preface

## Overview

Thank you for choosing INVT Flex series I/O system 6-channel EtherCAT branch module.

The INVT Flex series 6-channel EtherCAT branch module has one EtherCAT input port and five EtherCAT output ports, making it suitable for multi-axis complex equipment and production line networking where a star topology is required.

## Target audience

Personnel with electrical professional knowledge (such as qualified electrical engineers or personnel with equivalent knowledge).

## About documentation obtaining

In addition to this user guide, you can also obtain product documentation and technical support from our website:

Visit [www.invt.com](http://www.invt.com), choose **Support** > **Download**, enter a keyword, and click **Search**.

## Change history

The manual is subject to change irregularly without prior notice due to product version upgrades or other reasons.

No.	Change description	Version	Release date
1	First release.	V1.0	August 2024

# Contents

<b>1 Safety precautions .....</b>	<b>1</b>
1.1 What this chapter contains.....	1
1.2 Safety level definition .....	1
1.3 Personnel requirements.....	1
1.4 Safety guidelines.....	1
<b>2 Product overview .....</b>	<b>4</b>
2.1 Basic information.....	4
2.2 External interfaces .....	5
2.3 General specifications .....	5
2.4 EtherCAT communication specifications.....	6
<b>3 Electrical design .....</b>	<b>7</b>
3.1 Network cable fabrication requirements.....	7
3.1.1 Signal lead allocation .....	7
3.1.2 Length requirement.....	7
3.1.3 Technical requirements .....	7
3.2 Communication connection.....	8
3.2.1 EtherCAT connection.....	8
3.2.2 Communication system wiring .....	8
3.2.3 Configuration and usage Instruction .....	9
3.3 Wiring of power supply terminals .....	9
<b>4 Codesys usage example .....</b>	<b>10</b>
<b>5 Fault handling .....</b>	<b>13</b>
<b>Appendix A Dimensional drawing.....</b>	<b>14</b>

# 1 Safety precautions



## 1.1 What this chapter contains

Read this manual carefully and follow all safety precautions before moving, installing, operating and servicing the active power filter. Otherwise, equipment damage or physical injury or death may be caused.

We shall not be liable or responsible for any equipment damage or physical injury or death caused due to failure to follow the safety precautions.

## 1.2 Safety level definition


To ensure personal safety and avoid property damage, you must pay attention to the warning symbols and tips in the manual.






Warning symbols	Name	Description
	Danger	Severe personal injury or even death can result if related requirements are not followed.
	Warning	Personal injury or equipment damage can result if related requirements are not followed.


## 1.3 Personnel requirements


**Trained and qualified professionals:** People operating the equipment must have received professional electrical and safety training and obtained the certificates, and must be familiar with all steps and requirements of equipment installing, commissioning, running and maintaining and capable to prevent any emergencies.



## 1.4 Safety guidelines

General principles	
	<ul style="list-style-type: none"> <li>• Only trained and qualified professionals are allowed to carry out related operations.</li> <li>• Do not perform wiring, inspection or component replacement when power supply is applied. Ensure that all the input power supplies are disconnected before wiring and inspection.</li> <li>• The product design is applied to indoor electrical environments at overvoltage category II. Ensure that the power supply system of the product has lightning protection devices to prevent lightning overvoltage from being applied to the power input or signal I/O terminals of the product so as to avoid equipment damage.</li> <li>• Do not modify the product unless authorized; otherwise fire, electric shock or other injury may result.</li> <li>• Prevent cables and other conductive parts from falling into the product.</li> <li>• Do not contact the product with damp objects or body parts. Otherwise, electric shock may result.</li> </ul>

<b>Moving</b>	
	<ul style="list-style-type: none"> <li>• Select appropriate tools for product delivery, and take mechanical protective measures like wearing safety shoes and working uniforms to avoid personal injury.</li> <li>• Protect the product against physical shock or vibration.</li> </ul>
<b>Installation</b>	
	<ul style="list-style-type: none"> <li>• Do not install the product on inflammables. In addition, prevent the product from contacting or adhering to inflammables.</li> <li>• Do not run a damaged or incomplete product.</li> </ul>
	<ul style="list-style-type: none"> <li>• Install the product in a lockable control cabinet of at least IP20, which prevents the personnel without electrical equipment related knowledge from touching by mistake, since the mistake may result in equipment damage or electric shock. Only personnel who have received related electrical knowledge and equipment operation training can operate the control cabinet.</li> <li>• During installation, ensure that the modules are tightly connected and fastened. Insecure connection may cause problems such as communication failure and fall-off.</li> <li>• After installation, ensure that there are no obstructions on the vents of the product; otherwise, the chips of the product may be burned due to overheating and poor heat dissipation, which causes system control failure and misoperation.</li> </ul>
<b>Wiring</b>	
	<ul style="list-style-type: none"> <li>• Before wiring, clearly understand the necessary information including interfaces, power supply types, and specifications, and comply with relevant standards and requirements to ensure that the system wiring is correct.</li> <li>• To ensure personal safety and equipment use safety, reliably ground the product using cables with proper diameters and specifications.</li> <li>• Route the control signal and communication signal cables separately from cables with strong interference such as power cables.</li> <li>• Apply fastening means to long-distance or heavy cables.</li> </ul>
	<ul style="list-style-type: none"> <li>• Cut off all power supplies connected to the product before performing wiring.</li> <li>• Before power-on for running, ensure that each module terminal cover is properly installed in place after the installation and wiring are completed. This prevents a live terminal from being touched. Otherwise, physical injury, equipment fault or misoperation may result.</li> <li>• Install proper protection components or devices when using external power supplies for the product. This prevents the product from being damaged due to external power supply faults, overvoltage, overcurrent, or other exceptions.</li> </ul>

<b>Commissioning and running</b>	
	<ul style="list-style-type: none"> <li>• Before power-on for running, ensure that the working environment of the product meets the requirements, and a protection circuit has been designed to protect the product so that the product can run safely even if an external device fault occurs.</li> <li>• When the output units such as relays and transistors of the product are damaged, the output cannot be controlled to be On or Off as configured.</li> <li>• For modules or terminals requiring external power supply, configure external safety devices such as fuses or circuit breakers to prevent damage caused due to external power supply or device faults.</li> <li>• In the external circuit of the product, configure an emergency braking circuit, a protection circuit, a circuit for interlocking between forward and reverse operations, and an anti-equipment-damage switch for interlocking between the position upper limit and lower limit.</li> <li>• To ensure the safe running of equipment, design external protection circuits and safety mechanisms for output signals related to major accidents.</li> <li>• Design proper external control circuits to ensure the proper running of equipment, since outputs may be out of control when the control circuit has an exception.</li> </ul>


<b>Maintenance and component replacement</b>	
	<ul style="list-style-type: none"> <li>• Keep the product and its parts and components away from combustible materials and ensure they have no combustible materials adhered.</li> <li>• Before carrying out product maintenance or component operations, cut off all power supplies connected to the product.</li> <li>• Prevent the screws, cables and other conductive parts from falling into the product during maintenance or component replacement.</li> <li>• During maintenance and component replacement, take proper anti-static measures on the product and its internal parts.</li> </ul>
<b>Note</b>	<ul style="list-style-type: none"> <li>• Use proper torque to tighten screws.</li> </ul>

<b>Disposal</b>	
	<ul style="list-style-type: none"> <li>• The product contains heavy metals. Dispose of a scrap product as industrial waste.</li> </ul>
	<ul style="list-style-type: none"> <li>• Dispose of a scrap product separately at an appropriate collection point but not place it in the normal waste stream.</li> </ul>

# 2 Product overview

## 2.1 Basic information


Figure 2-1 Product nameplate



Model	Ordering code	Description	Applicable model
FC1160	11016-00020	Remote EtherCAT branch module, 1 EtherCAT input, 5 EtherCAT outputs	Applicable to INVT and third-party EtherCAT master devices

## 2.2 External interfaces

Figure 2-2 6 EtherCAT branch module interfaces



No.	Interface	Sign	Description
1	Power indicator	PWR	On: The power connection is normal.
			Off: The power connection is abnormal.
2	Net port indicator	Green indicator (Link)	On: Physical connection is established.
			Off: Physical connection is not established.
3	Net port indicator	Yellow indicator (Act)	Flash: There is data interaction.
			Off: There is no data interaction.
4	EtherCAT input port	X1	Port1, EtherCAT input, connecting to the upstream EtherCAT master.
5	EtherCAT output port	X2	Port2, EtherCAT output port, connecting to the downstream EtherCAT slave.
		X3	Port3, EtherCAT output port, connecting to the downstream EtherCAT slave.
		X4	Port4, EtherCAT output port, connecting to the downstream EtherCAT slave.
		X5	Port5, EtherCAT output port, connecting to the downstream EtherCAT slave.
		X6	Port6, EtherCAT output port, connecting to the downstream EtherCAT slave.
6	24V power interface	24V	DC 24V power supply +
		0V	DC 24V power supply -
		PE	PE

## 2.3 General specifications

Item	Specification
Rated input voltage	24VDC (20.4VDC–28.8VDC)
Rated input current	0.165A (typical value of input current at an input voltage of 24VDC)



Item	Specification
Communication protocol	EtherCAT industrial real-time bus protocol
EtherCAT channel	1 input, 5 outputs
Max. communication speed	100Mbps
Working temperature	-20°C~+55°C
Storage temperature	-25°C~+70°C (RH < 90%, no condensation)
Isolation	Input power isolation
Power supply protection	Protection against overcurrent, reverse connection, and surges

## 2.4 EtherCAT communication specifications

Item	Description
Communication protocol	EtherCAT industrial real-time bus protocol
Synchronization method	DC/SM
Duplex mode	Full duplex
Max. communication speed	100Mbps(100Base-TX)
Topology structure	Star topology structure
Transmission medium	Category 5e or higher network cables
Transmission distance	The distance between two nodes is less than 100m
Whether to support the branch module cascading	Supported
Network cable identification	Auto MDI/MDIX

# 3 Electrical design

## 3.1 Network cable fabrication requirements

Figure 3-1 EtherCAT network cable fabrication requirements





Figure 3-2 Network cable fabrication



**Note:** Please use shielded twisted-pair cables of category 5, plastic injection moulded and iron shelled.

### 3.1.1 Signal lead allocation

Pin	Signal	Signal direction	Signal description
1	TD+	Output	Data transmission+
2	TD-	Output	Data transmission-
3	RD+	Input	Data receiving +
4	--	--	Unused
5	--	--	Unused
6	RD-	Input	Data receiving +
7	--	--	Unused
8	--	--	Unused

### 3.1.2 Length requirement

FastEthernet technology confirms that when using the EtherCAT bus, the cable length between devices must not exceed 100 meters. Exceeding this length can cause signal attenuation, affecting normal communication.

### 3.1.3 Technical requirements

Perform a 100% conductivity test on the cables, ensuring there are no short circuit, opened circuit, dislocation or poor contact.

The EtherCAT bus uses shielded cables for network data transmission, and the following cable specifications are recommended.

Item	Specification
Cable standard	Elastic crossover cable, S-FTP, Category 5e

Item	Specification
Requirement	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB, EIA/TIA SB40-A&TSB36
Cross-sectional area of wire	AWG26
Conductor type	Twisted pair
Number of pairs	4

### 3.2 Communication connection


#### 3.2.1 EtherCAT connection

- When connecting the network cable, hold the crystal head of the cable and insert it into the Ethernet interface of the branch module until it makes a click sound.
- When removing the installed network cable, press the tail mechanism of the crystal head and pull out it from the product horizontally.

#### 3.2.2 Communication system wiring

The EtherCAT branch module can connect multiple EtherCAT slave devices. The system wiring diagram is shown below.

Figure 3-3 Communication system wiring






### 3.2.3 Configuration and usage Instruction


- When using this branch module, all EtherCAT slaves (including the four stations of the branch module) need to be configured to run in station alias mode. Otherwise, a failure in one branch may affect the normal operation of other branches.
- The port data flow priority of the 6-channel branch module is X2 > X3 > X4 > X5 > X6, indicating that any slave on the X2 branch takes priority over all slaves on the X3 branch.
- The branch module has DC mode enabled by default, indicating that the branch module is set to be an EtherCAT slave in DC mode.
- The branch module supports cascading, and the number of cascades is unrelated to the functionality of the branch module itself.
- Each branch module occupies four EtherCAT slave numbers.

### 3.3 Wiring of power supply terminals

■ Terminal definition


Schematic diagram	Left signal	Left terminal	Right terminal	Right signal
	24V	24V	24V	24V
	0V	0V	0V	0V
		PE	PE	

■ Terminal wiring




# 4 Codesys usage example


Step 1 Install the device description file "FC1160\_1.x.x.x.xml" in the "Device Repository."




Step 2 Complete the device connections, adding the EtherCAT master and network configuration.




- Add the devices behind X2 under the X2 interface.




- Repeat the same steps for the devices behind X3/X4/X5 by adding them to their corresponding interfaces, as shown in the figure below.



- Add the devices behind X6 OUT in the items after the FC1160.




After adding, the result is shown in the following figure.



Step 3 Compile and download the program to run.

**Note:**

- If there is no device, you can manually add the configuration. If there are devices, it is recommended to use the "Scan For Devices" to automatically scan the configuration.



- If communication fails, it is recommended to use the "Scan device" function to compare the physical configuration with the configured network configuration to verify their consistency.

## 5 Fault handling


When the module encounters a fault, you can check the signal state through the LED indicators and take corrective actions. Common fault states and their solutions are described below.

LED indicator	Net port indicator		Meaning	Cause	Solution
	PWR	Link			
Off	Off	Off	Abnormal power supply	<ul style="list-style-type: none"> <li>No power supply, or power supply is not connected.</li> <li>Internal circuit fault.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure that the power supply and wiring are normal.</li> <li>Replace the branch module.</li> </ul>
On	Off	Off	Network port is not connected.	<ul style="list-style-type: none"> <li>The communication cables may be detached, disconnected or short-circuited.</li> </ul>	<ul style="list-style-type: none"> <li>Check the connection of communication cables. If there are disconnections or short circuits, replace the communication cable.</li> </ul>
				<ul style="list-style-type: none"> <li>Branch module hardware fault</li> </ul>	<ul style="list-style-type: none"> <li>Replace the branch module.</li> </ul>
				<ul style="list-style-type: none"> <li>Master is not started.</li> </ul>	<ul style="list-style-type: none"> <li>Check the status of the master.</li> </ul>
On	On	No flashing	No data interaction	<ul style="list-style-type: none"> <li>The master is in communication stop state.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure that the master is in running mode.</li> </ul>
				<ul style="list-style-type: none"> <li>Master exception, data transmission stopped.</li> </ul>	



# Appendix A Dimensional drawing

Figure A-1 Installation dimensions (unit: mm)



*Your Trusted Industry Automation Solution Provider*



**Shenzhen INVT Electric Co., Ltd.**

Address: INVT Guangming Technology Building, Songbai Road, Matian,  
Guangming District, Shenzhen, China

**INVT Power Electronics (Suzhou) Co., Ltd.**

Address: No. 1 Kunlun Mountain Road, Science & Technology Town,  
Gaoxin District, Suzhou, Jiangsu, China

**Website: [www.invt.com](http://www.invt.com)**



INVT mobile website



INVT e-manual



6 6 0 0 1 - 0 1 3 7 9